

MEN'S MX CHEST PROTECTOR -



HOW TO MEASURE

A Chest:


Measure around the fullest part, under the armpits, keeping the tape horizontal.

B Torso Height:

Measure the vertical distance from the natural waist line to the shoulder.

C Height:

Stand against a wall, ask someone else to measure from the floor to the top of your head, keeping the tape vertical.



PRODUCT SIZE

BODY MEASUREMENT


INTL SIZE	A CHEST (CM)	B TORSO HEIGHT (CM)	C HEIGHT (CM)
XS-S	88-98	38-43	146-164
M-L	98-108	43-48	164-182
XL-2XL	108-118	48-51	182-194

PRODUCT SIZE

BODY MEASUREMENT

INTL SIZE	A CHEST (INCHES)	B TORSO HEIGHT (INCHES)	C HEIGHT (INCHES)
XS-S	34.6-38.5	15-17	57.5-64.5
M-L	38.5-42.5	17-18.9	64.5-71.7
XL-2XL	42.5-46.5	18.9-20	71.7-76.5

MEN'S & WOMEN'S OFF-ROAD HELMET - INTL



PRODUCT SIZE


HEAD MEASUREMENT

INTL SIZE	A HEAD CIRCUMFERENCE (CM)
XS	53 - 54
S	55 - 56
M	57 - 58
L	59 - 60
XL	61 - 62
XXL	63 - 64

INTL SIZE	A HEAD CIRCUMFERENCE (INCHES)
XS	20.8 - 21.2
S	21.6 - 22
M	22.4 - 22.8
L	23.2 - 23.6
XL	24 - 24.4
XXL	24.8 - 25.2

MEN'S MX / CYCLING PROTECTION NECK SUPPORT - INTL

SIZE GUIDE



HOW TO MEASURE

A Chest Circumference:

Using a measuring tape, measure the head circumference at the head's widest point.

B Chest Thickness:

Thickness of the chest in profile.

PRODUCT SIZE

CONVERSION GUIDE

BODY MEASUREMENT

BNS SIZE	U.S. SIZE	EURO SIZE	A CHEST CIRCUMFERENCE (CM)
XS-M	32-42	32-42	74-106
L-XL	42-56	42-56	106-134
INTL SIZE	U.S. SIZE	EURO SIZE	CHEST CIRCUMFERENCE (INCHES)
XS-M	32-42	32-42	29 1/4 - 41 3/4
L-XL	42-56	42-56	41 1/4 - 52 3/4

SUGGESTED SIZE TABLE (CM)

CONVERSION GUIDE


EURO SIZE	BODY MEASUREMENT		SUGGESTED SIZE
	A CHEST CIRCUMFERENCE (CM)	B CHEST THICKNESS	
38	74-78	SLIM, NORMAL, BARREL	XS-M
40	78-82	SLIM, NORMAL, BARREL	XS-M
42	82-86	SLIM, NORMAL, BARREL	XS-M
44	86-90	BARREL	XS-M
46	90-94	SLIM, NORMAL, BARREL	XS-M
48	94-98	SLIM, NORMAL, BARREL	XS-M
50	98-102	SLIM, NORMAL	XS-M
50	98-102	BARREL	L-XL
52	102-106	SLIM, NORMAL	XS-M
52	102-106	BARREL	L-XL
54	106-110	SLIM	XS-M
54	106-110	NORMAL, BARREL	L-XL
56	110-114	SLIM, NORMAL, BARREL	L-XL
58	114-118	SLIM, NORMAL, BARREL	L-XL
60	118-122	SLIM, NORMAL, BARREL	L-XL
62	122-126	SLIM, NORMAL, BARREL	L-XL
64	126-130	SLIM, NORMAL	L-XL
66	130-134	SLIM, NORMAL	L-XL
68	134-138	SLIM	L-XL

SUGGESTED SIZE TABLE (INCHES)

CONVERSION GUIDE

U.S. SIZE	BODY MEASUREMENT		BNS SIZE
	A CHEST CIRCUMFERENCE (CM)	B CHEST THICKNESS	
28	74-78	SLIM, NORMAL, BARREL	XS-M
30	78-82	SLIM, NORMAL, BARREL	XS-M
32	82-86	SLIM, NORMAL, BARREL	XS-M
34	70-74	BARREL	XS-M
36	74-78	SLIM, NORMAL, BARREL	XS-M
38	78-82	SLIM, NORMAL, BARREL	XS-M
40	82-86	SLIM, NORMAL	XS-M
40	82-86	BARREL	L-XL
42	70-74	SLIM, NORMAL	XS-M
42	70-74	BARREL	L-XL
44	74-78	SLIM	XS-M
44	74-78	NORMAL, BARREL	L-XL
46	78-82	SLIM, NORMAL, BARREL	L-XL
48	82-86	SLIM, NORMAL, BARREL	L-XL
50	78-82	SLIM, NORMAL, BARREL	L-XL
52	82-86	SLIM, NORMAL, BARREL	L-XL
54	70-74	SLIM, NORMAL	L-XL
56	74-78	SLIM, NORMAL	L-XL
58	70-74	SLIM	L-XL

KNEE BRACE SIZING



HOW TO MEASURE

A Knee:

Using a caliper, measure the width of the knee joint across the kneecap. The leg should be completely straight and in a weight-bearing position.

PRODUCT SIZE

BODY MEASUREMENT

INTL SIZE	A KNEE (CM)
S/M/L	9.8 - 11.2
XL/2XL	11.2 - 12.6

INTL SIZE

BODY MEASUREMENT

INTL SIZE	A KNEE (INCHES)
S/M/L	3.86 - 4.41
XL/2XL	4.41 - 4.96